



Pebble Time Steel Hardware buttons not working. Replacement

If your Pebble hardware buttons stopped working, including the middle button, soak it in vinegar for a day, to dislodged any hard water mineral deposits.

Written By: Danny Prieto



INTRODUCTION

If your Pebble hardware buttons stopped working, including the middle and back buttons, try soaking it in vinegar for a day before prying it open or scraping it. That is what I did and it dislodged some of the gar hard water mineral deposits in the button slots, making the buttons workable once again.

Step 1 — Pebble Time Steel Hardware buttons not working. Replacement



- If your Pebble hardware buttons stopped working, including the middle button, soak it in vinegar for a day, to dislodged any hard water mineral deposits.

If your Pebble hardware buttons stopped working, including the middle button, soak it in vinegar for a day, to dislodged any hard water mineral deposits.