



Performing Delphi MyFi XM2GO Hard Reset

This guide shows how to perform a hard reset on the device.

Written By: Aubrey





TOOLS:

- [Paper Clip](#) (1)
-

Step 1 — Removing Delphi MyFi XM2GO Battery Cover



- Turn over the Delphi MyFi XM2GO Device on its back to start the cover-removal process.

Step 2



- Locate the large button on the top back of the device.
- Press this button at the top while making a firm grip on the battery cover.
- As the button is pressed, move the cover towards the bottom of the device.
- The battery removal tab may pop up during the cover removal process.

Step 3 — Removing Delphi MyFi XM2GO Battery



- Holding the device, grab the tab with thumb and index finger.
- Pull down on the tab to move the battery block a few millimeters towards the bottom of the device to unlock the latch at the top.
- After the latch at the top is disengaged, pivot the battery away from the back and the battery will be free.

Step 4 — Performing Delphi MyFi XM2GO Hard Reset



- After removing the battery cover and battery, locate the reset (indicated by arrow).

Step 5



- ⚠ Unbend the paper clip, making it straight. CAUTION: The ends may be sharp.
- Carefully insert one end of the paper clip into the hole to reset the device.

To reassemble your device, follow these instructions in reverse order.