



# Philips Norelco Shaver 2100 Installing the pop-up trimmer Replacement

This guide which help you to successfully replace the popup trimmer.

Written By: Aum Patel



## INTRODUCTION

Follow this guide to replace the popup trimmer.

### TOOLS:

- T8 Torx Screwdriver (1)

## Step 1 — Pop-Up Trimmer




- Open the shaver head by pressing the button.

## Step 2



- Take off the two 10.1 mm screws #1 & #2 inside the shaver head using a 2.5 mm flat head screwdriver.

## Step 3



- Take the shaver head off.

## Step 4



- Open the pop up trimmer.

## Step 5



- Lift the trimmer out of the casing.
- *i* Take note that the metal prongs lie on the casing and fold over when the trimmer is closed.

To reassemble your device, follow these instructions in reverse order.