



Philips Phone CD295 Disassembly

Disassemble Philips Phone CD295 to clean the keyboard contacts

Written By: Keul



 **TOOLS:**

- tournevis cruciforme (1)

Step 1 — Philips Phone CD295 Disassembly




- Open the back by sliding it down

Step 2



- Remove the batteries and the 3 screws

Step 3



- Separate the white part of the brown one with a steel plate.
- Take care of the red cable of the back speaker
- The springs of the battery can go through the hole as shown in the second picture.
- Remove the 2 screws.

Step 4



- You have now access to the keyboard and can clean it.

To reassemble, follow instructions in back order