



Photive Rain Back Panel Replacement

Replace the back panel of your Photive Rain.

Written By: Shozaf Zaidi



INTRODUCTION

Use this guide to remove the back panel of the Photive Rain. Removing the back panel is necessary to access any of the speaker's internal components.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

Step 1 — Back Panel



(i) Turn the speaker off before disassembling.

- Pull the suction cup from its groove in the back of the speaker by twisting and turning it.

Step 2



- Remove the four 8.5 mm screws from the back panel of the speaker.
- Remove back panel

To reassemble your device, follow these instructions in reverse order.