



Pioneer A1 XW-SMA1-K Front Panel Replacement

Replacing the front panel on your Pioneer A1 XW-SMA1-K speaker.

Written By: Drew Dickenson



INTRODUCTION

If you need to replace the front mesh on your Pioneer A1 XW-SMA1-K speaker this guide will explain you how to remove the front cover using the iFixit spudger. This shows how to properly remove the front panel so that you can clean it or replace it.

TOOLS:

- Metal Spudger (1)

Step 1 — Front Panel



- Use the spudger to remove the mesh front panel.

To reassemble your device, follow these instructions in reverse order.