




# Pioneer A1 XW-SMA1-K Speaker Replacement

How to replace Pioneer A1 XW-SMA1-K speakers.

Written By: Luke Patton



## INTRODUCTION

If you are looking to replace the speaker in your Pioneer A1 XW-SMA1-K then this is a guide instructing you how to.

### TOOLS:

- [Metal Spudger \(1\)](#)
- [Phillips #1 Screwdriver \(1\)](#)

## Step 1 — Front Panel




- Use the spudger to remove the mesh front panel.

## Step 2 — Speaker



- Use a Phillips #1 screwdriver to remove the thirteen 12 mm screws in the speaker frame.
- Remove the speaker frame by pulling vertically and flip to reveal the speakers.

## Step 3



- Use a Phillips #1 screwdriver to remove the eight 12 mm screws from the left and right speakers.

## Step 4



- Remove the left and right speakers from the speaker frame by pulling gently up and detaching the wires.

To reassemble your device, follow these instructions in reverse order.

