




Pioneer FH-X730BS Fuse Replacement

How to replace the fuse on the back of the Pioneer FH-X730BS.

Written By: Cody Pesta



INTRODUCTION

A blown fuse can cause the Pioneer FH-X730BS to be unusable. This guide will show you how to replace the appropriate fuse.


TOOLS:

- Slip Joint Pliers (1)

PARTS:

- 10 amp fuse (1)

Step 1 — Fuse



- Remove the fuse on the back of the Pioneer FH-X730BS. This may require some force. Pliers can be used if needed.
- Replace old fuse with a new one of identical amperage.

To reassemble your device, follow these instructions in reverse order.