



Planet Eclipse Etha Trigger Replacement

This guide will instruct you on how to replace the trigger on your Planet Eclipse Etha.

Written By: Evan Hench



INTRODUCTION

The trigger on the Etha doesn't break often, but you may choose to replace it for a trigger you prefer or it may simply need cleaning.

TOOLS:

- Macro Bit Set (1)

Step 1 — Battery and Grip Panels



- Use the 5/64" hex key to remove the screw shown.
- Remove the grip panel by gently holding the bottom of the panel and lifting the panel off.

(i) If you are only replacing the battery, skip the next step.


(i) The screws in this guide are interchangeable with those shown in the Eyes replacement guide.

Step 2




- Flip the marker over and use the 5/64" hex key to remove the screw shown.
- Remove the grip panel by gently holding the bottom of the panel and lifting the panel off.

Step 3



- Carefully remove the 9V battery and connector.
- Remove the 9V battery from the connector.

Step 4 — Trigger



- Use a hex key to unscrew the middle screw on the top of the trigger.

Step 5



- Use same hex key to push through trigger retention pin on the side of the gun.

Step 6



- Pull out the trigger by grabbing the bottom and slowly rotating outwards.

To reassemble your device, follow these instructions in reverse order.