



Polaroid Automatic 100 Back Lens of the Viewfinder Replacement

This is a step by step guide that explains how to replace the viewfinder of your Polaroid 100 Automatic Land Camera.

Written By: Katie Miller



This document was generated on 2019-09-22 02:28:17 AM (MST).


INTRODUCTION

The viewfinder is the square piece on top of the camera that houses a square glass eye that you look through to see what you are taking a photo of.

TOOLS:

- Phillips #0 Screwdriver (1)

Step 1 — Back Lens of the Viewfinder



- Use a Phillips #0 screwdriver to remove the two 20 mm screws on the back of the viewfinder.

Step 2



- Remove the back cover of the viewfinder.
- Push out the lens that is flush with the back of the viewfinder cover.

To reassemble your device, follow these instructions in reverse order.