




Polaroid PMID4312 Battery Replacement

This guide will show you how to replace the battery of Polaroid PMID 4312.

Written By: Christopher Bertan




INTRODUCTION

Power is one of the biggest problems of the polaroid PMID 4312 tablet. This guide will show you how to replace the battery.

TOOLS:

- [iFixit Opening Tools](#) (1)
- [Plastic Cards](#) (1)
- [Soldering Iron](#) (1)

Step 1 — Battery



- Pry the seam between the screen and the case and slide it on all four sides with a large plastic opening tool until the plastic case comes off.

Step 2




- Lift the device off of the case and flip over the device so that it sits screen side down.

Step 3




- The device is now free from the plastic case.

Step 4



- Wedge a plastic card beneath the battery unit and wiggle the card side to side and up and down gently until the glue sealing the battery to the device is broken.

Step 5



- Peel back any yellow tape not directly attached to the battery.
- Using a soldering iron, desolder the two wires that connect the battery to the motherboard.

To reassemble your device, follow these instructions in reverse order.