



Polaroid S10 Removing the backcover Replacement

Prerequisite Only


Written By: Christofer



 **TOOLS:**

- [iFixit Opening Picks set of 6 \(1\)](#)
- [Metal Spudger Set \(1\)](#)

Step 1 — Removing the backcover



- Place an opening pick between the volume button and the back cover.
- More than one pick may be needed, but avoid placing more than two picks in the same space.
- ⚠ Excessive force on the pick will break the volume button.
- Carefully remove the back cover using the metal spudger.
- It is normal to hear a snapping noise due to the plastic tabs on the back cover.

To reassemble your device, follow these instructions in reverse order.