



# Power on HTC Desire HD

This guide will teach you how to power your phone on.

Written By: NotTelling



## INTRODUCTION

This guide will teach you how to power your phone on.

## Step 1 — Turn on your Desire HD



- Reach up to the top of the device.
- Press and hold the power button for 3 seconds.

## Step 2



- Your device should now be on.
- If it doesn't turn on:
  - Make sure you held the power button long enough.
  - Connect the charger (The battery may be flat)
  - Make sure a battery is present in the battery slot.
  - If all else fails, refer to instruction manual or contact HTC Customer support.

To turn the device off: 1. Unlock the Device 2. Hold the power button (3 secs) 3. Tap on the "Power Off" Button

This document was generated on 2020-02-27 05:24:58 PM (MST).

