



PowerBook 3400 M3553 Keyboard Replacement

How to remove and replace the keyboard.

Written By: Michael Mondragon



INTRODUCTION

If your keyboard is malfunctioning you can remove the keyboard to clean it. If that doesn't solve your problem you will need to replace the keyboard.

TOOLS:

- [Spudger](#) (1)
- [T8 Torx Screwdriver](#) (1)

Step 1 — Battery



- Close the screen and turn the PowerBook over. Orient the computer so the text of the label is right side up.

Step 2



- Press and hold the button on the left of the front side, and slide the battery out.

Step 3 — Keyboard



- With a T8 torx screwdriver, remove the three 24mm torx screws along the middle of the back panel.

Step 4




- Turn the computer over and open the display. You should see that the keyboard is loose.

⚠ Before attempting to remove the keyboard, note that a ribbon cable connects the keyboard to the logic board. Improper removal may damage your keyboard.

- Carefully lift the front of the keyboard up slightly, and then slide the keyboard towards yourself.
- Then carefully lift the top half of the keyboard, and rotate it towards yourself.

Step 5



- Loosen the ribbon cables connecting the keyboard to the computer by using a plastic opening tool to lift the tabs on either side of the cable port.
- Gently remove the ribbons from its tabs.

To reassemble your device, follow these instructions in reverse order.