



PowerBook G4 Titanium DVI Battery Replacement

Written By: Walter Galan



INTRODUCTION

Remove the PowerBook G4 Titanium DVI battery.

Step 1 — Battery



- Locate the battery release tab on the underside of the G4.
- Slide the battery release tab to the left and lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.