



PowerBook G4 Titanium Onyx Airport Card Replacement

Written By: iRobot



INTRODUCTION

Install an original Airport 802.11b card internally.



TOOLS:

- T8 Torx Screwdriver (1)



PARTS:

- Airport Card (1)

Step 1 — Lower Case



- Turn the G4 over.
- Remove the eight T8 Torx screws from the lower case.

Step 2



- Using your thumbs, slide the lower case away from you.
- *(i)* The lower case may stick in the front on a tab just above the center of the DVD drive. Be careful as you work the case off, or you may break the thin strip of plastic just above the drive.
- Lift the lower case off.

Step 3



- Your laptop should look approximately like this.

Step 4 — Airport Card



- Skip this step if your computer does not have an Airport card.
- Firmly grasp the plastic tab attached to the Airport card and pull up and to the left.
- Disconnect the antenna cable from the left side of the Airport card.

To reassemble your device, follow these instructions in reverse order.