



PowerLead Pluto PLD003 Battery Replacement

This guide will show you how to remove and replace your battery.

Written By: Justin Tew



Step 1 — Battery



- Remove the strap by lifting the Velcro and gently pulling it out of the metal hoop.

Step 2



- On the side of the camera slide the eject button to the right. This will open the plastic battery door.

Step 3



- Place your thumb in the indent on the left side of the battery and carefully apply pressure to slide battery out.

To reassemble your device, follow these instructions in reverse order.