



PowerShot G7 X Mark II Battery Replacement

This guide will show you how to replace the battery, and secure the battery compartment door on the PowerShot G7 X Mark II.

Written By: Brandon



INTRODUCTION

This guide will show you how to replace the battery, and secure the battery compartment door. This guide will be useful if the battery is dead.

Step 1 — Battery



- On the bottom of the camera, slide the latch on the battery cover toward the center of the camera.
- The spring-loaded battery door will open revealing the battery inside.

Step 2



- Move the latch from the top of the battery to release it.
- The battery is spring loaded and should pop out from the compartment.

To reassemble your device, follow these instructions in reverse order.