



Protocol Dronium 3x Rotor Guards Replacement

How to replace the rotor guards on the Protocol Dronium 3x.

Written By: Alexander George



INTRODUCTION

The Protocol Dronium 3x rotor guards are responsible for protecting the drone's props. Additional rotor guards are included with the Dronium 3x.

TOOLS:

- Phillips #0 Screwdriver (1)

Step 1 — Rotor Guards



- Set the drone upright.
- Using the Phillips #0 screwdriver, remove the 6mm screw from each corner of the drone.
- Place the rotor guards aside and replace with guards of choice.

To reassemble your device, follow these instructions in reverse order.