



# Razer Blackwidow Tournament Edition Chroma Front Panel Replacement

This guide shows you how to remove the front panel on the Razer Blackwidow Tournament Edition Chroma.

Written By: Jonathan Stewart





This document was generated on 2019-09-22 08:07:02 AM (MST).

 **TOOLS:**


- [iFixit Opening Tools \(1\)](#)
- [Phillips #1 Screwdriver \(1\)](#)

## Step 1 — Rubber Feet



- Turn the keyboard over so that it is lying flat on its face.
- Use the iFixit opening tool to pry the rubber feet off the keyboard.

## Step 2 — Front Panel



- Use a Phillips #1 screwdriver to remove the six screws on the back of the keyboard.
- Then use the iFixIt opening tool to pry off the front panel.
- Place the keyboard over so the keys are facing up.
- Lift both ends of the keyboard up removing the front panel.

To reassemble your device, follow these instructions in reverse order.