




Razer Blade Stealth 2016 Fan Replacement

This guide is meant to help replace the two fans inside the Razer Blade Stealth 2016 laptop.

Written By: Katie Murphy



INTRODUCTION

The purpose of computer fans is to cool down the device. As the computer is operating, the device produces heat. The fans will bring cooler air in to cool down the device. The fans are meant to cool the device down, if this part fails to do this, the computer could shutdown and need a reboot. If your fans in your Razer Blade Stealth 2016 isn't working properly, this guide will show you how to remove and replace the fans.

TOOLS:

- [T4 Torx Screwdriver \(1\)](#)
- [Phillips #00 Screwdriver \(1\)](#)

Step 1 — Battery




- Use a Torx 4 screwdriver to remove the eight 3.04 mm screws on the back case and remove the rear cover by prying up lightly starting in one of the corners.

Step 2




- Remove the battery carefully by removing the six screws using the T4 Torx screwdriver.

Step 3




- Unplug and remove battery from the device.

Step 4 — Fans




- Remove the three 3.38 mm screws from the left fan (this fan should be black).

Step 5



- Carefully lift and remove the left fan.

Step 6



- Repeat steps five and six to remove the silver, right fan.

To reassemble your device, follow these instructions in reverse order.