



# Remington Pearl Pro The plate Replacement

This guide will help step by step, in order to replace the floating plates on the Remington Pearl pro.

Written By: Katie Tijerina



---

## INTRODUCTION

This guide will help step by step, in order to replace the plate on the Remington Pearl pro. The floating plates on the device are not working properly, they will not heat up in order to use the straighter. The thirty second heat up also fails to work, so in order for them to work we must replace to solve the issue.



### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — The Floating plates



- Unscrew the two screws right below the floating plates with Philips 0 screwdriver.

To reassemble your device, follow these instructions in reverse order.