



Removing Fender Frontman 15r Back panel

Written By: Greg Sawers



INTRODUCTION

Need to get inside the amp? Remove the back panel!

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)
- [Spudger](#) (1)

Step 1 — Back panel



⚠ Be sure to unplug the device before proceeding.

- Use a Phillips #0 screwdriver to remove the four 21.7mm screws holding the back panel to the frame.

Step 2



- Once the screws are out, use a plastic opening tool or spudger to pry the top of the back panel open. There may be some resistance, but it will eventually pry loose.

Step 3



- Once the top is separated, use your hand to remove the back panel from the unit.

To reassemble your device, follow these instructions in reverse order.