



Removing Nokia 1100b RH-36 Front Cover

How to remove the front cover of the Nokia 1100b.

Written By: JSwan



INTRODUCTION

This will guide you through removing the front cover from the main body of your Nokia 1100b RH-36.

Step 1 — Removing Nokia 1100b RH-36 Front Cover



- Firmly grip the back of the casing.
- Separate the front and back casings either by pulling them apart from the middle or gently prying the front off with your fingers from the bottom.

⚠ Be sure not to bend the casing too much when prying from the bottom. Failure to do so may cause it to crack.

To reassemble your device, follow these instructions in reverse order.