



Repairing Display

Step by step instructions to reconnect loose wire between the monitor and laptop of a Compaq Presario CQ60 Notebook PC.

Written By: duncan



INTRODUCTION

This guide will show you how to dismantle the laptop in order to reestablish loose connection between the monitor and laptop of a Compaq Presario CQ60 Notebook PC .

TOOLS:

- precision screw drivers (1)

Step 1 — Display



- Remove the 6 outer screws on the underside of the laptop.
- Open the battery compartment and remove the 7 visible screws.
- Pry the corners of the bezel at the base of the keyboard, pushing up until it loosens.
- Carefully remove the ribbon connections of the keyboard, power button, and wifi button.
- Disconnect and re-connect the white monitor ribbon located on the left side to make sure it sits firmly in the connection.
- Reassemble the laptop by following these steps in reverse.
- The monitor should work when powered on again.

To reassemble your device, follow these instructions in reverse order.