



# Repairing Parrot Bebop Drone Bottom Parts

Use this guide to replace the lower assembly including: engines, cross, rubber pieces, feet, and antennas.

Written By: David Hoyt



## INTRODUCTION

Use this guide to replace the lower assembly including: engines, cross, rubber pieces, feet, and antennas.

[video: [http://youtu.be/\\_M3DZ7X-RCg](http://youtu.be/_M3DZ7X-RCg)]

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Phillips #0 Screwdriver](#) (1)
- [Precision Utility Knife](#) (1)
- [iFixit Opening Tools](#) (1)
- [Spudger](#) (1)
- [T8 Torx Screwdriver](#) (1)

To reassemble your device, follow these instructions in reverse order.