



Replacement OlyPocket 10 Batterie

OlyPocket electric agenda

Written By: Mohamed Mediouni



INTRODUCTION

Replace the Battery of an electronic agenda.

TOOLS:

- Essential Electronics Toolkit (1)

Step 1 — Batterie



- 1. Unscrew the back with a small philips screwdriver.
- 2. Place a CA-2032 battery into the back
- 3. Screw the cover back on

To reassemble your device, follow these instructions in reverse order.