



# Ring Spotlight Cam Battery Lights Replacement

This guide will help you replace the lights in the Ring Spotlight Cam Battery.

Written By: Smoo Rena



## INTRODUCTION

If you are having trouble with the motion-activated lights and you would like to replace them, follow the 4 steps that are provided. It will take approximately 15-35 minutes.

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Metal Spudger](#) (1)

## Step 1 — Lights



- Remove the top plastic pad by peeling it off with a metal spudger.

## Step 2



- Remove the 7 PH00 screws around the four corners with PH00 of the lid.

## Step 3



- Use the metal spudger set to break the glue lining and the motion sensor will pop out.

To reassemble your device, follow these instructions in reverse order.