



# Roland G-800 Top cover Replacement

Written By: Andrew



 **TOOLS:**

- Phillips #2 Screwdriver (1)

## Step 1 — Top cover



- Turn the keyboard upside down to access the screws
- Remove 15 Philips PH2 screws
- *i* Don't worry about the other 16 screws, they hold the keys to the bottom case.

## Step 2



- Turn the keyboard upright again and lift the top cover from the front
- Remove 6 connectors

To reassemble your device, follow these instructions in reverse order.