



Ryobi VC120 Battery Replacement

This guide will help you remove and replace your vacuum's battery.

Written By: Allison Schoch



INTRODUCTION

Use the guide to replace your battery in a few simple steps.

Step 1 — Battery



- To remove your battery, hold both of the rear buttons down simultaneously and pull backwards on your battery compartment.

To reassemble your device, follow these instructions in reverse order.