



Samsung 3D Blu-ray Player Power Cord Replacement

Replace your Samsung's power cord.

Written By: Boston



INTRODUCTION

In this guide we will show how to remove the casing on the Samsung and then take out a damaged power cord.

TOOLS:

- Small Phillips Head Screwdriver (1)

Step 1 — Power Cord



- There are two of these pieces, as they are the sides of the player. They simply slide off.

Step 2



- There is one screw holding the case on, and it is on the middle of the top of the back of the player. (Right above the outputs) **IMPORTANT:** When you take the case off, take especial care to not break any connections between the internal circuitry and the inside of the top casing. Fold it over like shown in the image.

Step 3



- Power Cord and connection to circuit board. (in white)

Step 4



- Pull the cable to disconnect the connector.

Step 5



- And its out. To reassemble the device, repeat the guide in reverse order.

To reassemble your device, follow these instructions in reverse order.