



Samsung BlackJack Hard Reset

Perform a hard reset on your Samsung Blackjack.

Written By: Kristin Manna



INTRODUCTION

Use this guide to perform a hard reset.

Step 1 — Samsung BlackJack Hard Reset



- Press and hold the power button located on the top of the phone to turn off the phone.

Step 2



- Press and hold the "UP" navigation button and the "End Call" buttons simultaneously for five seconds.

Step 3



- Press and hold down the power button to turn the phone back on.
- Follow the on-screen instructions to complete the reset.

To reassemble your device, follow these instructions in reverse order.