



# Samsung Chromebook Pro Battery Replacement

This guide will demonstrate how to replace the battery in the Samsung Chromebook Pro.

Written By: Amber Castro-Beltran



This document was generated on 2020-03-12 08:34:58 AM (MST).

## INTRODUCTION

Use the guide below to replace the battery for the Samsung Chromebook Pro.

### TOOLS:

- [JIS #000 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)
- [Precision Tweezers Set](#) (1)

## Step 1 — Battery




- Remove the eight 30 mm screws from the edges of the case with the JIS J000 screw bit.

## Step 2



- Slide the plastic opening tool in a corner at a steep angle, and lift to remove the outer case.

## Step 3



- Remove the four 30 mm screws surrounding the battery with the JIS J000 screw bit.

## Step 4



- Lift the connecting wires to disconnect from the slot with the precision tweezers.
- Lift battery to remove once the wire is disconnected.

To reassemble your device, follow these instructions in reverse order.