



Samsung Galaxy Player 4.2 Battery Replacement

How to remove and replace the battery in your Samsung Galaxy Player 4.2.

Written By: Dan Brown



INTRODUCTION

This guide will walk you through replacing the battery on your Samsung Galaxy Player 4.2. Fortunately, the battery replacement process is quick and easy and requires no special tools.


Step 1 — Battery



- Use your finger to press in the battery cover tab on the upper right hand corner of the back of the device.
- Pry the battery cover off the device by pressing in and lifting up.

★ When reassembling, align the top portion of the back cover to the top of the device and press down until it clicks into place.

Step 2



- Press your finger into the groove on the bottom left hand side of the battery.
- Pry the battery out by lifting your finger up.

To reassemble your device, follow these instructions in reverse order.