



Samsung Galaxy S10 Battery Disconnect

Prerequisite step only. Disconnects the battery for the Galaxy S10.

Written By: Arthur Shi



INTRODUCTION


Prerequisite guide only! Battery disconnect step for the Galaxy S10.



TOOLS:

- [Spudger](#) (1)
-

Step 1 — Samsung Galaxy S10 Battery Disconnect



- Insert the flat end of a spudger underneath the battery connector, which is attached to the motherboard below the rear-facing camera.
- Pry upwards to disconnect the connector from its socket.
 - ⚠ When you disconnect connectors like these, be careful not to dislodge the small surface-mounted components surrounding the socket.
- Gently push the battery's flex cable away from the motherboard socket to prevent accidental contact.

To reassemble your device, follow these instructions in reverse order.