



# Samsung Galaxy S7 Active Disassembly

How to disassemble the screen of Samsung Galaxy S7 Active.

Written By: Chengbin Owen Kuang



## INTRODUCTION

This guide will show you how to disassemble the screen of Samsung Galaxy S7 Active.

### TOOLS:

- Heat Gun (1)
- Metal Spudger (1)
- Tweezers (1)

### PARTS:

- Samsung Galaxy S7 Active Screen (1)

## Step 1 — Samsung Galaxy S7 Active Disassembly



- Melt the adhesive on the screen by applying a blow dryer directly on the screen.

 Your phone is hot, please do not touch it with your bare hand.

## Step 2



- Wedge the metal spudger in between the screen and the frame to begin separating them.

 It would be easier to separate the screen from the sealing adhesive on the frame if you use more than one metal spudger.

 Your phone might no longer be watertight after you reassemble it.

## Step 3



- Slide the metal spudger around the phone at least once.

*(i)* It would be easier to slide your metal spudger if you apply the blow dryer to where you are currently sliding.

## Step 4



- Lift the screen up with your hands.

**⚠** Please wash your hands thoroughly with hot water and soap after you finish.

To reassemble your device, follow these instructions in reverse order.