



Samsung Galaxy S7 Power/Volume Button Flex Replacement

This video shows how to replace power/volume button flex for Samsung Galaxy S7. Come and replace it by yourself according to this replacement tutorial.

Written By: Witrigs

Samsung Galaxy S7 Power & Volume Flex



This document was generated on 2019-09-21 07:40:05 AM (MST).

INTRODUCTION

Having issues with your phone's power & volume button? Side button is not working? Power & volume button stop responding? Use this guide to learn how to fix the unresponsive power and volume key on the Samsung Galaxy S7. Replace it by yourself according to this replacement tutorial.

[video: https://www.youtube.com/watch?v=BJff1V_Thu8]

TOOLS:

- Tweezers (1)
- Spudger (1)
- Phillips #000 Screwdriver (1)
- Heat Gun (1)
- iFixit Opening Picks set of 6 (1)
- Heavy-Duty Suction Cups (Pair) (1)

PARTS:

- Galaxy S7 Volume Button Cable (1)
- Galaxy S7 Rear Cover Adhesive (1)
- Galaxy S7 Volume Button Bracket (1)
- Galaxy S7 Power Button Bracket (1)
- Galaxy S7 Power Button Cable (1)

To reassemble your device, follow these instructions in reverse order.