



# Samsung Galaxy Tab 3 10.1 Front-Facing Camera Replacement

Written By: Corey Brown



 **TOOLS:**

- iFixit Opening Picks set of 6 (1)
- Spudger (1)
- Tweezers (1)

 **PARTS:**

- Galaxy Tab 3 10.1 Front Camera (1)

## Step 1 — Rear Case



- Insert an opening pick between the rear case and the plastic rim.
- You may need to add multiple picks to detach the clips.
- Slide the pick along the edge of the rear case until you release the plastic clips attaching the rear case to the display.
- Continue to slide the pick around the edge of the rear case until all clips are released.

## Step 2



- Lift the case up to remove it.


## Step 3 — Front-Facing Camera



- Lift the plastic frame to remove.

 Avoid the three delicate ribbon cables.

## Step 4



- Use the flat end of a plastic spudger to pry up the press-fit connector from the motherboard.
- Remove the camera by gently pulling upward with a pair of tweezers.

To reassemble your device, follow these instructions in reverse order.