



Samsung Galaxy Tab 4 10.1 digitizer glass only screen Replacement

Written By: enavar10



 **TOOLS:**

- [Spudger \(1\)](#)
- [Tweezers \(1\)](#)
- [iSesamo Opening Tool \(1\)](#)
- [iOpener \(1\)](#)
- [Plastic Cards \(1\)](#)

Step 1 — digitizer glass only screen



Step 1

- **Left off back case with flat tool carefully.**
- **Get between the glass and case.**

● Insert wisdom here.

Step 2



Step 2

- **Left off back case exposing the back of the tablet.**


● Insert wisdom here.

Step 3



Step 3

- **Disconnect battery carefully lifting with tweezers.**





- Insert wisdom here.

Step 4


Step 4

- **Locate LCD ribbon and remove tape**



- Insert wisdom here.

Step 5



Step 5

- Carefully lift the back clip.
- Then remove ribbon from the connector.

- Insert wisdom here.

Step 6


Step 6

- Flip over and use heat to loosing the adhesive tape.



- Insert wisdom here.

Step 7




Step 7

- Use a flat tool to get under the adhesive tape try to stay away from the the bottom where the home button is located

button is located
bottom where the home

- Insert wisdom here.

Step 8




- Using cards glade under adhesive tape reapplying heat as needed.



- Get cards all around top, left, and right of the tablet.

- Insert wisdom here.

Step 9



Step 9

- Carefully begin to lift the top towards the bottom reapplying heat if needed.

- Insert wisdom here.

To reassemble your device, follow these instructions in reverse order.