




Samsung Galaxy Tab A 9.7 Speakers Replacement

Use this guide to replace the Samsung Galaxy Tab A 9.7 speakers.

Written By: Paulina Nguyen



This document was generated on 2019-10-10 04:06:03 PM (MST).

INTRODUCTION

The speakers in your device can be affected by a couple things such as dirt being stuck in them or simple usage over a long amount of time. Use this guide to replace them, bringing clear and new sound back to your device

TOOLS:

- Heavy-Duty Spudger (1)
- Metal Spudger (1)

PARTS:

- [Galaxy Tab A 9.7 \(Wi-Fi\) Left Speaker \(1\)](#)
- [Galaxy Tab A 9.7 \(Wi-Fi\) Right Speaker \(1\)](#)



Step 1 — Back Cover



- Insert a metal spudger between the back case and the screen of the device.
- The back cover is attached to the device by a series of snaps. The snaps are positioned about an inch from each other.
- Move the spudger along the perimeter of the device while it is in between the back case and the screen to open each snap.


(i) There will be an audible click every time a snap releases.

Step 2 — Speakers



- Remove the two 2.8 mm Phillips #000 screws from the speakers.

Step 3



- ⓘ Each speaker is now only connected to the main device by small plastic snaps.
- Pry the speakers from the device at these two points using the heavy duty spudger.

To reassemble your device, follow these instructions in reverse order.