





# Samsung Mythic SGH-a897 Speaker Replacement

Replace a faulty speaker in your Samsung Mythic SGH-a897.

Written By: Morgan Yost



## INTRODUCTION

This guide will show you how to replace a faulty speaker.

### TOOLS:

- [iFixit Opening Tools](#) (1)

## Step 1 — Battery



- Slide your fingernail into the slit at the bottom of the phone to remove the back cover.

## Step 2



- Place your finger in either of the bottom corner of the battery slot and lift to remove the battery.

## Step 3 — Rear Case




- Remove six 5 mm Phillips #0 screws from the back of the phone.

## Step 4



- Insert a plastic opening tool into the seam between the back case and the rest of the phone.
- Working along the seam, pry the back from the phone.

## Step 5 — Speaker



- Find the back casing of the phone. Slide the plastic opening tool under the bottom of the speaker to pop it out.

To reassemble your device, follow these instructions in reverse order.