




Samsung NP350E5C-A02US hard drive and memory stick cover Replacement

How to remove the hard drive and memory stick cover.

Written By: James Kingrey



INTRODUCTION

If you need to remove the cover over the hard drive and memory sticks this guide will show you how.

TOOLS:

- Phillips #0 Screwdriver (1)

Step 1 — Hard drive and memory stick cover




- Remove the M2.5x5 mm screw with a Phillips #0 screwdriver.

Step 2



- Slide the cover 1/4" towards the front of the laptop.

Step 3



- Then, lift the cover off.

To reassemble your device, follow these instructions in reverse order.