



# Samsung NaviBot SR8855 disassembly

How to easily disassemble your NaviBot vacuum cleaner.

Written By: martinuk



## INTRODUCTION

How to easily disassemble your NaviBot vacuum cleaner, allowing you to clean it from time to time, or to replace a defective part (in my case, the bag presence switch: Error C08, cost 3 Euros).

### TOOLS:

- Kreuzschlitzschraubendreher PH 2 (1)

## Step 1 — Samsung NaviBot SR8855 disassembly



- Remove the dust basket.

## Step 2



- Move the switch to "0".
- Unscrew the battery cover.

## Step 3




- Disconnect the battery and remove it.

## Step 4



- Remove the 2 screws and 2 plastic pieces.

## Step 5



- Withdraw the front guard.
- Disconnect the connector.

## Step 6



- Remove the guards on each side.

## Step 7



- Remove the 2 screws and the cover on each side.

## Step 8



- Remove the 2 screws.

## Step 9



- Slide the top upwards (watch out for 4 clips).

## Step 10



- Remove the 6 screws.

## Step 11



- Take off the top cover, and there you have it - your NaviBot is dismantled!

To reassemble your device, follow these instructions in reverse order.