



Samsung SC-MX20 Battery Replacement

This guide will cover the replacement of the battery of your Samsung SC-MX20.

Written By: Matthew Madeja



INTRODUCTION

A battery can lose charge and require a replacement or charge. It is necessary to understand how to replace this. This guide will show you how to remove and replace the internal battery from the Samsung SC-MX20 Camera.

Step 1 — Battery



- Open cover by sliding away from the device.
- Pull the release lever down and the battery will pop up from the device. Remove the battery from the device.

To reassemble your device, follow these instructions in reverse order.