



Samsung SCH-3500 Battery Replacement

How to replace a Samsung SCH-3500 battery.

Written By: Brett Tomashitis



This document was generated on 2020-01-27 09:23:29 AM (MST).

INTRODUCTION

This guide demonstrates how to replace the battery on the Samsung SCH-3500.

Step 1 — Battery



- Place the phone so that the back is facing you. Depress the locking tab on the back of the phone with a finger or thumb.

Step 2



- Slide the battery toward bottom of the phone, about a quarter of an inch, to clear the hooks that keep it secured to the back of the phone.

Step 3



- Lift the battery away from the phone case.

To reassemble your device, follow these instructions in reverse order.