



Samsung SCH-U340 Battery Replacement

Written By: Mitchell Walker



INTRODUCTION

This guide shows how to replace the battery in a Samsung SCH U340 cell phone. This is important because it is a prerequisite for all other repair guides.

Step 1 — Battery



- Turn the cell phone so that the back side is facing you. Press the upper indent and slide the back cover down.

Step 2



- Pull battery up from indent at the bottom and slide it out.

Step 3



- Set the battery aside.