



Samsung SGH-X105 Earpiece Speaker Replacement

Written By: Chris Lao



INTRODUCTION

Replacing the earpiece speaker

TOOLS:

- 1.5 mm Flathead Screwdriver (1)
- Phillips #00 Screwdriver (1)

Step 1 — Battery



- Rotate the phone onto its front side so that the LCD screen is facing away from you.

Step 2



- Remove the battery by pressing down on the battery release button while sliding the battery downwards.

Step 3 — Front & Back Panels



- Remove the four small black screws that secure the back phone panel using the Phillips #00 screwdriver.
- *i* Complete removal of screws may not be necessary.

Step 4



- Carefully separate the front and back panels by gently prying them apart. Start at the bottom of the phone (near the AC charger input).
- *i* Volume control button will be unsecured and may fall out as soon as the panels are separated.
- *i* Gentle force may be required to separate the panels at the top latch.
- *i* There are two wires connecting the front and back panels. Be careful not to rip these wires out when separating the panels.

Step 5



- Using your nails, tweezers, or any precise grabbing tool, pinch the antenna wire connector (clear plastic plug) and pull gently. It should pop out rather easily.

Step 6 — Earpiece Speaker



- Put aside the back panel. You will only be working with the front panel from here on.

Step 7



- Using a SL 1.5 flathead screwdriver (or any small prying tool), pry the speaker from the plastic front cover.
- ⓘ The earpiece speaker is magnetic so you can use a magnet to remove the earpiece speaker from the plastic front cover once loosened.
- ⚡ You can apply your own adhesive to secure your replaced speaker if desired during reassembly.

To reassemble your device, follow these instructions in reverse order.