




Samsung Series 5 3G Chromebook Battery Replacement

This guide will demonstrate how to replace a battery in your Chromebook.

Written By: Helder Avelino



INTRODUCTION

If your Chromebook is not charging properly or its not turning on, you may need to replace the battery.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [Spudger \(1\)](#)

Step 1 — Back Cover




- Make sure your Chromebook is powered off before you begin.
- Place the laptop on a flat surface with the bottom side facing up.
- Remove the rubber feet from the bottom of the panel. The easiest way to do this is to use your fingernails to pick them out.
- Remove all the seven screws in the bottom panel.

Step 2




- Loosen the back cover panel by using the flathead screwdriver or the spudger.

Step 3



- Once you work your way around, you can remove the panel.

Step 4 — Battery



- The Chromebook battery can be removed after twisting out three Phillips screws and disconnecting it from the motherboard.

To reassemble your device, follow these instructions in reverse order.