



Samsung Series 7XE700T1A Volume Button Replacement

the following guide will be use to replace the volume button


Written By: james



 **TOOLS:**



- [iFixit Opening Tools \(1\)](#)

Step 1 — Back panel



- Wedge the opening tools inside the device and move it around the perimeter until you have loosened the adhesive that is keeping it together.

Step 2



- With your hands, open up the back panel, separating it from the tablet.

Step 3 — Volume Button



- Now that the back panel has been removed, using your fingers, push out the volume button from the inside.

To reassemble your device, follow these instructions in reverse order.