



Sega Dreamcast Expansion Bay Replacement

Written By: wkwong



INTRODUCTION

A guide to remove the expansion bay from the Sega Dreamcast.

Step 1 — Expansion Bay



⚠ Verify that the console is disconnected from the AC outlet before you begin.

- **Flip the console over on its back.**
- **Take note of your model number**, in case replacement parts are needed.

Step 2



- **Remove the expansion bay** by applying pressure to the small clip on the expansion bay while prying it away from the console.

To reassemble your device, follow these instructions in reverse order.